

Assembly of rotating keypads

If using the AC7752 adapter plate, mount this to the front of the door first.

Position the AC9090 rotating mount plate.

Fasten the AC9090 with the threaded bolts.



Insert the spindle into the keypad (spindle cut to the correct length). Insert the cable into the spindle cable guide. The spindle and cable can now be guided through the safe door.

Position the keypad at 11:00 o'clock and rotate the keypad until it clicks into place.

